

## **Corrections to Modular Organizer pattern**

Every effort is made to create patterns that are complete and correct. On occasion a correction is needed.

The directions for constructing the Pen Module beginning on the bottom of page 14 should read as follows\*:

### Pen Storage Module

Cut (25) **2 3/4"** x 3 1/4" sections of cardstock.

Score and fold at **5/8"** intervals, leaving a 1/4" tab along one side.

Roll to form square tube. Make 25.

Assemble tubes into a 5 x 5 grid.

Attach 1/2" x 3 1/4" strips as bands around front and back edge of grid as shown.

**For thin pens (such as Ranger Distress Markers) you can make the tubes 3/4" square (cut (36) 2 1/4" x 3 1/4", scoring at 1/2" intervals). Create a grid of 6 tubes x 6 tubes. Add additional 1/2" x 3 1/4" shims as needed.**

**For thick pens (such as Spectrum Noir Markers) you can make the tubes 3/4" square (cut (16) 3 1/4" x 3 1/4", scoring at 3/4" intervals). Create a grid of 4 tubes x 4 tubes. Add additional 1/2" x 3 1/4" shims as needed.**

Continue construction of module as noted on pattern.